


# OPUS-SPD

## Remote Speed Control for OPUS 100B & 150B Units

### Installation Guide


Figure 1.



The OPUS-SPD operates on low voltage and is connected to the fan as figure 2.

The device incorporates a remote rotary dial to adjust the fan running speed.

Figure 2. Wiring diagram.




## Installation

Remove the plastic cover held by the two sprung base tags. (see figure 3).

Release the circuit board and remove the lower rectangular knockout. Bring the Low Voltage cable and connect as figure 2. Fix the circuit board.

Figure 3.



The base assembly can be offered up to the chosen mounting position and the fixing points marked through prior to drilling. Plug the surface if necessary before fixing. Replace front cover.